

# PHANTOM 3




ADVANCED

## In the Box


Check that all of the following items are in your package. If any items are missing, please contact DJI or your local dealer.

### Essentials


Aircraft Body x1




Remote Controller x1




Propeller Pairs x4



Intelligent Flight Battery x1



Battery Charger x1



Power Cable x1



Manuals



*In the Box*

*Phantom 3 Professional / Advanced Safety Guidelines and Disclaimer*

*Phantom 3 Intelligent Flight Battery Safety Guidelines*

*Phantom 3 Advanced Quick Start Guide*

### Accessories\*

Gimbal Clamp x1



Vibration Absorbers x4



16GB Micro-SD Card x1



Micro-USB Cable x1



Anti-drop Kit x2



Landing Pads x4



Propeller Removal Clamp x1



Stickers x4  
(Silver, red, blue, pink)

